

GT 120 - GTUC 120 - GT 220 - GTUC 220

en

Control panel

DIEMATIC 3 - FM129

DIEMATIC 3 CH - FM133



**Installation
instructions**

Contents

1	Symbols used	3
2	General	3
3	Installing the outside sensor	4
3.1	Positions to be avoided	4
3.2	Installing the outside sensor	4
4	Fitting the flow sensor	5
5	Electrical connections	6
5.1	Important recommendations	6
5.2	Type of connection	6
5.3	General	6
5.4	Terminal block	7
5.5	Basic connections	8
5.6	Connecting circuit B	9
5.7	Connecting the options	10
5.8	Connection of a second domestic hot water tank	11
5.9	Pool connection	12
5.10	Connecting a pool and preparation for solar heated domestic hot water	14
5.11	Connecting one or two circuits with mixer valve	15
5.12	Hot water storage tank connection	16
5.13	Basic connections if the installation is in cascade and when connecting to a regulation DIEMATIC VM	17
6	Skeleton Diagrams	20

1 Symbols used

 **Caution danger**

Risk of injury and damage to equipment. Attention must be paid to the warnings on safety of persons and equipment

 **i Specific information**

Information must be kept in mind to maintain comfort

 **Reference**

Refer to another manual or other pages in this instruction manual

DHW: Domestic hot water

2 General

- **Control panel assembly**

 See: Boiler installation instructions.

- **Fitting the boiler sensor**

 See: Boiler installation instructions.

- **Connection of the water circuit for domestic use**

 See: Calorifier instructions.

- **Installing options**

 See: Option instructions.

- **Parameter settings and installation configuration**

 See: Control panel technical instructions.

3 Installing the outside sensor

Choose a location:


- on one face of the area to be heated, on the north if possible
- under the influence of meteorological variations
- protected from direct sunlight
- easy to access

Z: Inhabited area controlled by the sensor


H: Inhabited height controlled by the sensor

A: recommended position on a corner

B: Possible position




3.1 Positions to be avoided



8800N002A


3.2 Installing the outside sensor

- ① CB Ø 4 wood screw + Inserts (provided)



4 Fitting the flow sensor

■ Heating circuit with mixing valve



8518N108

The flow sensor with connecting cable (length 2.5 m) and connector plug should be fitted to the outlet circuit pipe concerned and must be connected to the point provided in the control panel as shown hereafter.

The flow sensor after the valve must be positioned around 0.5 m after the 3 way valve or after the heating pump if this is fitted to the outlet.

- Cut the pipe insulation by 50 mm.
- At the point where the sensor is fitted, thoroughly clean the pipes (there must be no trace of paint) and coat them with the ready-to-use contact paste provided in the syringe.
- Secure the sensor with the collar provided for this purpose.

i The flow sensor must not be covered by the insulation around the pipe.

5 Electrical connections

5.1 Important recommendations

! The power supply must be cut prior to any intervention on the heating installation (for example, via the appropriate fuse or a general switch) and any restart must be prevented.

! Connections must be made by a qualified technician

! Do not modify the connections inside the control panel.


i All connections are made to the terminals on the control panel.

i Separate the sensor cables from the 230 V cables.


In the boiler: Use the boiler's 2 grommets:
Use 2 cableways at least 10 cm apart.

i Attach the cables to the cable clamps provided for this purpose.

■ GT 220



- ① 230 V main supply
For Switzerland: Power supply cable Supplied
- ② Sensors
- ③ Cable clamps



5.2 Type of connection

For the 230 V electrical connections, use 3-wire cables with a cross-section of 1,5 mm².

! Keep to the polarity shown on the terminals: phase (L), neutral (N) and earth (---).

5.3 General

Make the electrical connections of the appliance according to:

- The instructions of the prevailing standards,
- The instructions on the circuit diagrams provided with the appliance,
- The manufacturer's instructions.


Power the appliance via a circuit which includes a remote omnipolar switch with a gap of more than 3 mm.

Earthing shall comply with standard NFC 15100 (France) or RGBT (Belgium).

! The available output per outlet is 450 W (2 A, with $\cos \phi = 0,7$) and the inrush current must be lower than 16 A.
If the charge exceeds one of these values, relay the command using a contactor (fitted outside the control panel).

5.4 Terminal block

■ State on delivery



1(A) All countries except Switzerland:

To connect the mixing valve PCB + sensor options - See:
Instructions for option FM48, AD217

1(B) For Switzerland:

To connect the mixing valve PCB + sensor options - See:
Instructions for option FM48, AD217

2 Boiler sensor

3 Boiler remote control input


4 Alarm output

5 Connecting the TELCOM vocal telesurveillance module
See chapter: Connecting the options

6 Flue gas thermostat

5.5 Basic connections

i For Switzerland: circuit B
See next page




- 1 230 V main supply
- 2 Flue gas thermostat
- 3 Burner fault alarm light
- 4 Pump circuit A
- 5 D.H.W. load pump
- 6 DHW sensor
- 7 Titanium anode
- 8 Outside sensor
- 9 Boiler sensor
- 10 Boiler with or without accumulator

11 Boiler with accumulator

8375NS76-A

5.6 Connecting circuit B

i Originally for Switzerland, FM48 option for other countries.



- (1) If using a two-way motor
Connect open to terminal 23 (), close to terminal 22 () and neutral to terminal 24 (N).
- (2) If using a thermal motor
Connect between terminal 23 (open) and terminal 2 (N).

(1) If using a two-way motor

Connect open to terminal 23 (), close to terminal 22 () and neutral to terminal 24 (N).

If using a thermal motor

Connect between terminal 23 (open) and terminal 2 (N).

Attention Achtung Caution
raccorder les fils vert/jaune sur la languette de masse
Grün/Gelbe Drähte an Masse schliessen
connect the yellow/green wire to ground


OPTION - ZUBEHÖR

OPTION - ZUBEHÖR

8675N394B

5.7 Connecting the options

For example: Solar collector, TELCOM vocal telesurveillance module, remote controls for circuits A and B, flue gas sensor.




- 1 230 V main supply
- 2 Flue gas thermostat
- 3 Burner fault alarm light
- 4 Pump circuit A
- 5 DHW sensor (Package AD212)
- 6 Titan Active System® simulation connector (package AD212)
- 7 Outside sensor
- 8 Boiler sensor
- 9 Outlet sensor
- 10 Interactive remote control (package FM51 or FM52)
- 11 Flue gas sensor
- 12 TELCOM voice remote monitoring module (depending on its availability in your country)
- 13 Solar sensor probe

- 14 Boiler with or without accumulator
- 15 Boiler with accumulator
- 16 DHW sensor (Package AD160)
For connection of solar collectors: adjust the **S.AUX** parameter (# FITTER PARAM.) to **SOLAR**.
- 17 D.H.W. load pump
- 18 Solar load pump

5.8 Connection of a second domestic hot water tank

This connection is possible if circuit A is not used




If connecting a second DHW tank, use circuit A:

- set the **CIRC.A** parameter (#. INSTAL PARAM.) to **DHW**.
- Fit the sensor (package AD 212) into the second DHW tank.
- Connect the sensor to the **S.AUX** input.
- Adjust the **TEMP.DHW A** set temperature using the key 40-80°C range to obtain a domestic hot water calorifier type operation.

5.9 Pool connection

This connection is possible if circuit A is not used



8575N581-A

- 1 230 V main supply
- 2 Flue gas thermostat
- 3 Burner fault alarm light
- 4 Swimming pool sensor (Package AD212)
- 5 Pool secondary pump
- 6 Primary pump pool
- 7 Outside sensor
- 8 Boiler sensor

■ Controlling the pool circuit

The DIEMATIC 3 regulation can be used to control a pool circuit in **two different cases**:

- **Case 1**

The regulation DIEMATIC 3 regulates the primary circuit (boiler / exchanger) and the secondary circuit (exchanger / pool).

- Set the value of **TPC D** to the temperature which corresponds to the needs of the exchanger.
- Set the parameter **S.AUX (#FITTER PARAM.)** to **SWIM.P.**
- Set the parameter **CIRC. A: (#FITTER PARAM.)** to **SWIM.P.**
- Connect the primary circuit pump (boiler/exchanger) to the pump A outlet. The **TPC J** temperature is then maintained during programme A comfort periods in **summer** and in **winter**.
- Connect the pool sensor (package AD212) to the **S.AUX:** input.
- Set the value of the pool sensor using key  in the range 0.5-39°C or to **FF** (Frost Free).
- With an **FF** setting, the primary pump starts up and the secondary pump stays off if the installation's antifreeze function is activated.

- **Case 2**

The pool has already a regulation system that is to be kept. The DIEMATIC 3 control unit only regulates the primary circuit (boiler/exchanger).

- Set the value of **TPC D** to the temperature which corresponds to the needs of the exchanger.
- Set the **CIRC.A** parameter in **#INSTAL PARAM.** to **POOL**
- Connect the primary circuit pump (boiler/exchanger) to the pump A outlet. The **TPC J** temperature is then maintained during programme A comfort periods in **summer** and in **winter**.

■ Hourly programming of the secondary circuit pump


The secondary pump operates during programme A comfort periods in summer and winter alike.

■ Stopping

 To prepare your pool for winter, consult your pool specialist.

5.10 Connecting a pool and preparation for solar heated domestic hot water

This connection is possible if circuit A and either circuit B or C are not used.



- 1 230 V main supply
- 2 Flue gas thermostat
- 3 Burner fault alarm light
- 4 Primary pump pool
- 5 Pool secondary pump
- 6 Swimming pool sensor (Package AD212)
- 7 DHW sensor
- 8 DHW sensor (Package AD212)
- 9 D.H.W. load pump
- 10 Solar load pump
- 11 Outside sensor
- 12 Boiler sensor
- 13 Titan Active System® simulation connector
(package AD 212)

- 14 Solar sensor probe

■ Parameter settings

- Fit the mixing valve PCB + sensor option (Package FM 48)
- adjust the **S. AUX** parameter to **SWIM. P.**
- adjust the **CIRC.A** parameter to **SWIM. P.**
- adjust the **CIRC.B** parameter to **SOLAR**

5.11 Connecting one or two circuits with mixer valve




To connect the mixing valve PCB + sensor options - See:

Instructions for option FM48

For Switzerland:

1 PCB + sensor for a mixing valve is already prefitted to the control panel.

5.12 Hot water storage tank connection



- 1 230 V main supply
- 2 Flue gas thermostat
- 3 Burner fault alarm light
- 4 Pump circuit A
- 5 Outside sensor
- 6 Boiler sensor
- 7 Titan Active System® simulation connector (package AD212)
- 8 DHW sensor (Package AD212)
- 9 Hot water storage tank sensor (Package AD160)
- 10 Buffer tank
- 11 D.H.W. load pump
- 12 Heating load pump

The storage tank handles heating and DHW production.

Package AD160 contains 2 sensors:

- The sensor for the solar panel is used as a storage tank sensor
- The sensor for the storage tank is used as a DHW sensor

■ Parameter settings

Set the parameter STOR.T.SENS (#CONFIGURATION) to ON.

■ Operation

• In DHW production:

Operation is the same as the normal operation. The boiler setting only is equal to the DHW setting +10 K. The heating load pump is off.

• In heating mode:


The burner and the heating load pump:

- are off if the temperature of the storage tank is higher than the boiler setting.
- start up if the temperature of the storage tank falls below the boiler setting -6 K.

5.13 Basic connections if the installation is in cascade and when connecting to a regulation DIEMATIC VM

(Without option AD217)

5.13.1 Master boiler 1




- 1 230 V main supply
- 2 Flue gas thermostat
- 3 Burner fault alarm light
- 4 Primary injection pump
- 5 D.H.W. load pump
- 6 Titan Active System® simulation connector (package AD 212)
- 7 DHW sensor
- 8 D.H.W. loop back pump

- 9 Outside sensor
- 10 Boiler sensor
- 11 Boiler with or without accumulator
- 12 Boiler with accumulator
- 13 To the Diematic VM (1) regulation
- 14 To 2 secondary boiler (1)


(1) The boiler can be connected to a boiler in cascade or to a DIEMATIC VM using a BUS cable (package AD134 or DB119).

5.13.2 Secondary boiler



- 1 230 V main supply
- 2 Flue gas thermostat
- 3 Burner fault alarm light
- 4 Primary injection pump
- 5 Boiler sensor (Follower boiler)
- 6 Boiler with or without accumulator
- 7 From the previous cascade boiler
- 8 Not used
- 9 Boiler sensor on common output

5.13.3 Cascade



- 1 Master boiler
- 2 Secondary boiler
- 3 Primary injection pump
- 4 Common outlet sensor to be connected to the S ECS input on boiler
②
- 5 Mixing valve and circulating pump
To connect the mixing valve PCB + sensor options, See: Instructions for option FM48

To construct the cascade, set the parameter **CASCADE (#CONFIGURATION)** on each boiler to 1 and 2 respectively.


Set the parameter **CIRC. A: to PRIM.P.** on boiler ①.

The boilers switch over every 7 days.

If necessary, the startup of the secondary boiler is timed at 4 minutes.

6 Skeleton Diagrams

Schéma de principe - Stromlaufplan - Principle diagram - Principeschema "DIEMATIC III"



Plan n° : 3000089992-001-A



DE DIETRICH THERMIQUE S.A.S



www.dedietrich-thermique.fr
 Direction des Ventes France
 57, rue de la Gare
 F- 67580 MERTZWILLER
 ☎ +33 (0)3 88 80 27 00
 ☎ +33 (0)3 88 80 27 99

REMEHA GmbH



www.remeha.de
 Rheiner Strasse 151
 D- 48282 EMSDETEN
 ☎ +49 (0)25 72 / 9161-0
 ☎ +49 (0)25 72 / 9161-102
 info@remeha.de

DE DIETRICH



www.dedietrich-otoplenie.ru
 129164, Россия, г. Москва
 Зубарев переулок, д. 15/1
 Бизнес-центр «Чайка Плаза»,
 офис 309
 ☎ +7 (495) 221-31-51
 info@dedietrich.ru

VAN MARCKE



www.vanmarcke.be
 Weggevoerdenlaan 5
 B- 8500 KORTRIJK
 ☎ +32 (0)56/23 75 11

NEUBERG S.A.



www.dedietrich-heating.com
 39 rue Jacques Stas
 L- 2010 LUXEMBOURG
 ☎ +352 (0)2 401 401

DE DIETRICH THERMIQUE Iberia S.L.U.



www.dedietrich-calefaccion.es
 C/Salvador Espriu, 11
 08908 L'HOSPITALET de LLOBREGAT
 ☎ +34 935 475 850
 info@dedietrich-calefaccion.es

DE DIETRICH SERVICE



www.dedietrich-heiztechnik.com
 ☎ Freecall 0800 / 201608

WALTER MEIER (Klima Schweiz) AG



www.waltermeier.com
 Bahnstrasse 24
 CH-8603 SCHWERZENBACH
 ☎ +41 (0) 44 806 44 24
 Serviceline +41 (0)8 00 846 846
 ☎ +41 (0) 44 806 44 25
 ch.klima@waltermeier.com

WALTER MEIER (Climat Suisse) SA

www.waltermeier.com
 Z.I. de la Veyre B, St-Léger
 CH-1800 VEVEY 1
 ☎ +41 (0) 21 943 02 22
 Serviceline +41 (0)8 00 846 846
 ☎ +41 (0) 21 943 02 33
 ch.climat@waltermeier.com

DUEDI S.r.l.



www.duediclima.it
 Distributore Ufficiale Esclusivo
 De Dietrich-Thermique Italia
 Via Passatore, 12 - 12010
 San Defendente di Cervasca
 CUNEO
 ☎ +39 0171 857170
 ☎ +39 0171 687875
 info@duediclima.it

DE DIETRICH



www.dedietrich-heating.com
 Room 512, Tower A, Kelun Building
 12A Guanghua Rd, Chaoyang District
 C-100020 BEIJING
 ☎ +86 (0)106.581.4017
 +86 (0)106.581.4018
 +86 (0)106.581.7056
 ☎ +86 (0)106.581.4019
 contactBJ@dedietrich.com.cn

BDR Thermea (Czech republic) s.r.o.



www.dedietrich.cz
 Jeseniova 2770/56
 130 00 Praha 3
 ☎ +420 271 001 627
 dedietrich@bdrthermea.cz

AD001-AM

© Copyright

All technical and technological information contained in these technical instructions, as well as any drawings and technical descriptions supplied, remain our property and shall not be multiplied without our prior consent in writing.

Subject to alterations.

27/11/2015



300003765-001-02

De Dietrich

DE DIETRICH THERMIQUE
 57, rue de la Gare F- 67580 MERTZWILLER - BP 30