



# Overview of basic DHW installation\*

## CTC EcoZenith i360



Indoor model with heat pump control



\*This overview is only intended as an aid to installation; all safety and installation instructions in the Installation and Maintenance Manual for the product must be followed.

## CTC EcoZenith i360

Indoor model with heat pump control



Terminal block X2

\*\*B103 – current sensor not applicable to 1x230

\*This overview is only intended as an aid to installation; all safety and installation instructions in the Installation and Maintenance Manual for the product must be followed.